

FR - ATTENTION!
 GB - WARNING!
 DE - ACHTUNG!
 NL - WAARSCHUWING!
 IT - AVVERTENZA!

+3

ans
 years
 Jahre
 jaar
 anni















X1




Smoby

FR - Outils non fournis
 GB - Tools not provided.
 DE - Werkzeug nicht inbegriffen
 NL - Gereedschap niet inbegrepen
 IT - Utensili non forniti



<p>A</p>	 <p>I21015</p>	<p>x1</p>	<p>E</p>	 <p>out2463</p>	<p>x1</p>
<p>B</p>		<p>x1</p>	<p>F</p>	 <p>S16013</p>	<p>x1</p>
<p>B1</p>	 <p>I21016</p>	<p>x1</p>	<p>G</p>	 <p>I16026</p>	<p>x1</p>
<p>C1</p>	 <p>I21018</p>	<p>x1</p>	<p>H</p>	 <p>I16028</p>	<p>x1</p>
<p>C2</p>	 <p>I21017</p>	<p>x1</p>	<p>C3</p>	<p>J</p>	 <p>I16027</p>



FR • non fournis
 GB • not provided.
 DE • nicht inbegriffen
 NL • niet inbegrepen
 ES • no incluidas
 PT • não fornecidas.
 IT • non forniti
 DK • medfølger ikke.
 SE • ingår inte.
 FI • työkäluja
 NO • følger ikke med
 HU • nem tartozékai a terméknek.
 CZ • není součástí dodávky
 SK • nie je súčasťou dodávky
 PL • niedostarczone w zestawie.
 BG • не са предоставени.
 RO • neincluse
 GR • δεν περιλαμβάνονται
 SI • ni priloženo.
 HR • se ne isporučuju

TR • dahil değildir
 RU • не поставляются.
 UA • не входять у комплект
 EE • ei ole kaasas.
 LT • komplektą nėra
 LV • komplektā nav ietverti.

•AR الأدوات غير مُرفقة مع المنتج.