# North American Fort Block House

Assembly

1 -
Glue the card portholes (1) and door frame (2) to the wall panels.

Glue the block house walls (A, B, C, D) to the inner firing platform (E).

Score the card roof panel (G) and fold, glue to the roof supports (F).

Position as required.

1

G

F

A

B

1

E

D

2

C

6180B1

ITALERI

SARISSA PRECISION LTD

North American Fort
Palisade and Gate

Assembly

1 -
Glue the palisade wall brace (A) to the back of the wall panel (B).

Glue the wall support trusses (C) to the back of the wall.

Glue the wall assembly to the base panel (D).

2 -
Glue the side palisade wall brace (E) to the back of the gate wall panel (F).

Glue the gate wall brace (G) to the back of the gate wall panel.

Glue the wall support trusses (H) and the gate trusses (J) to the gate wall.

Glue the gate frames (L) to the gate panels (M).

Slot the gates into the pivot points.

3 -
Glue the palisade wall panels (O) to the wall brace (P).

Glue the wall support trusses (R) to the back of the walls.

Glue the assembly to the base panel (S).

Position the walls where required.